









EXCAVATOR (190T)

PART NUMBER	DESCRIPTION	PICTURE
UMA150-100-C30	ADAPTER CENTRAL	
UMA150-100-SL30	ADAPTER SPLIT LEG	
UM150RC	TOOTH	
UM150P	PIN	
ULS100C340	LIP SHROUD CENTRAL	
ULS100L340	LIP SHROUD LEFT	
ULS100R340	LIP SHROUD RIGHT	
UBS100S	BASE	
URT100S	RETAINER	



WHEEL LOADER (90T and UP)

PART NUMBER	DESCRIPTION	PICTURE
U007-080C30	ADAPTER CENTRAL	
U007-080L30	ADAPTER LEFT	
U007-080R30	ADAPTER RIGHT	
U070WL	TOOTH	
U070P	PIN	
U070C	RETAINER	



WHEEL LOADER (94T and up)

WULF
WEAR PARTS


WULF PART NUMBER

DESCRIPTION

PICTURE

UM150-120C22

ADAPTER



UM150WL

TOOTH



UM150P

PIN

